

POOL

CHECK™

eXact™ Strip

PART NUMBER 481649

The eXact™ Strip Br (481649) offers the safest and most convenient delivery system for your Bromine testing with the eXact™ Meter. All reagents, as identified in the Standard Methods AWWA Handbook (4500-Cl G.), are contained in the eXact™ strip pads.



**Pool Check™
eXact™ Strip
For Bromine**

**(For Use With eXact™
1,2,3 & 9 Meters)**

Available For Private Label.

Test Procedure (eXact™ 2 meter example):

Step 1: Remove one eXact™ Strip br from the bottle. Recap the bottle immediately. Set strip in a dry place.

Step 2: Rinse supplied plastic vial 1 or 2 times and fill to line with pool water sample. DO NOT OVERFILL! Dry outside of vial with a soft paper or cloth towel.

Step 3: Lift the chamber lid and insert plastic vial. Close lid.

Step 4: Press the "Menu" key to switch the meter on and display the "br" symbol.

Step 5: Press the "B" key to blank the meter to 0.

Step 6: Open the chamber lid and dip the eXact™ Strip br into the plastic vial for 20 seconds with gentle back and forth motion as illustrated.

Step 7: Remove and discard the strip; immediately close the lid and push the "R" key. Record result.

Detection Range:

Bromine: 0-10.0 mg/L

Packaging:

Bottle of 50 eXact™ strips

INDUSTRIAL TEST SYSTEMS, Inc.

1875 Langston Street, Rock Hill, SC 29730

Phone: 1-800-861-9712 Fax: 1-803-329-9743

For International: 001-803-329-9712 ext 220 (Pablo)

Web: www.poolcheckonline.com Email: its@cetlink.net



Member of



The Association of
Pool & Spa Professionals