

POOL

CHECK™

eXact™ Strip

PART NUMBER 481653

The eXact™ Strip O₃ (481653) offers the safest and most convenient delivery system for your Ozone testing with the eXact™ 9 Meter. All reagents, as identified in the Standard Methods AWWA Handbook (4500-Cl G.), are contained in the eXact™ strip pads.



**Pool Check™
eXact™ Strip
For Ozone**

**(For Use With
eXact™ 9 Meter)**

Available For Private Label.

Test Procedure (eXact™ 9 meter example):

1. Press the **ON** key to start the unit. By default the instrument starts with the last test program that was used.
2. Push the **O₃** key to select Ozone.
3. Push the **↓** key to activate the test program.
4. Fill one plastic vial to the marked 10ml line with your water sample to be tested.
5. Place the vial into the test chamber and push the **↓** key to blank the instrument. Be sure the vial is fully seated in the test chamber.
6. *Without removing the vial from the test chamber*, remove one **eXact™ Strip O₃** and dip into the vial for **20 seconds** with a gentle back-and-forth motion.
7. Remove the strip and discard.
8. Push the **↓** key and read the LCD display.
9. Record your results.

Detection Range:

Ozone: 0 - 2.0 mg/L

Packaging:

Bottle of 50 eXact™ strips

INDUSTRIAL TEST SYSTEMS, Inc.

1875 Langston Street, Rock Hill, SC 29730

Phone: 1-800-861-9712 Fax: 1-803-329-9743

For International: 001-803-329-9712 ext 220 (Pablo)

Web: www.poolcheckonline.com Email: its@cetlink.net



Member of



The Association of
Pool & Spa Professionals