

POOL

CHECK™

eXact™
Strip

PART NUMBER 481655

The eXact™ Strip pH (Type B) (481650) offers the safest and most convenient delivery system for your pH testing with the eXact™ 9 Meter. All reagents, as identified in the Standard Methods AWWA Handbook, are contained in the eXact™ strip pads.



Pool Check™
eXact™ Strip
For pH (Type B)

*(For Use With eXact™
9 Meters)*

Available For Private Label.

Test Procedure (eXact™ 9 meter example):

1. Press the **ON** key to start the unit. By default the instrument starts with the last test program that was used.
2. Push the **pH** key to select pH.
3. Push the **↓** key to activate the test program.

pH - PHENOL RED INSERT BLANK

The following text will be displayed on the LCD:
4. Fill one plastic vial to the marked 10ml line with your water sample.
5. Place the vial into the test chamber and push the **↓** key. Be sure the vial is fully seated in the test chamber.
6. *Without removing the vial from the test chamber*, remove one **eXact™ Strip pH** and dip into the vial for **20 seconds** with a gentle back-and-forth motion.
7. Remove the strip, discard, and **wait 20 seconds**.
8. Push the **↓** key and read the LCD display.

pH - Phenol red 7.4 pH

9. Record your results.

Detection Range:

pH: 6.8-8.4

Packaging:

Bottle of 50 eXact™ strips



INDUSTRIAL TEST SYSTEMS, Inc.

1875 Langston Street, Rock Hill, SC 29730

Phone: 1-800-861-9712 Fax: 1-803-329-9743

For International: 001-803-329-9712 ext 220 (Pablo)

Web: www.poolcheckonline.com Email: its@cetlink.net

Member of

