

eXact[®] MICRO 8

The new eXact[®] Micro 8 Advanced Photometer from Industrial Test Systems, Inc. (ITS) is the perfect meter for all your water quality testing needs. No visual color matching required means the eXact[®] Micro 8 takes the guesswork out of water testing.

- **Direct read parameters: Cyanide, Iron (Fe⁺² / Fe⁺³), Ammonia, Phosphate, pH (5 - 10), Sulfide**
- **Easy-to-use eXact[®] Strip/Photometer reagent delivery system (US Patent #7,333,194) delivers reagents safely without the need to count drops or crush tablets**
- **0.01 ppm (mg/L) precision with no visual color matching required**
- **Waterproof meter (IP-67) and it floats**
- **2-Year warranty with satisfaction guarantee**
- **Automatic test timer & 140 test memory (saves last 20 tests per menu)**
- **Autocalibrated meter**
- **No-slip grip housing and simple 3-button control**
- **Lightweight**
- **Environmentally friendly (recyclable parts and uses 60% less reagents than 10mL sample tests)**
- **Private labeling and menu customization available**
- **Tests 12 additional parameters in Transmission Mode (Visit www.sensafe.com for details)**

For more information about this and our complete line of test strips, reagent and water quality testing devices, please call or email as listed below.

**WATERPROOF
(IP-67)**



TECHNICAL SPECIFICATIONS:

Measurement Method:	Photometric Light Source: Light Emitting Diode (LED)
Wavelength:	638 nm
Memory:	20 tests per menu; 140 total
Programmed Tests:	Cyanide, Iron (Fe ⁺² /Fe ⁺³), Ammonia, Phosphate, BT-pH, Sulfide
Transmission Mode Tests:	Total Alkalinity, Aluminum, Biguanide, Calcium (CaCO ₃), Chloride (NaCl), Cyanuric Acid, Magnesium, CG-pH, Potassium, Protein (BSA), Sulfate (SO ₄), Turbidity
Transmission Range:	100 - 0.00 %T
Photometric Precision:	+/- 0.1/0.01 %T
Display:	3-digit customized liquid crystal display with annunciators
Cell Pathlength:	20mm
Cell Chamber:	Custom-molded, proprietary, PET plastic fused into chamber, non-removable
Sample Required:	4 mL (0.13 oz)
Reagent System:	Utilizes patented eXact [®] Strip Micro reagent delivery system
Operating Temperature Range:	0 - 50°C (32° - 122°F)
Power Supply:	(4) AAA alkaline batteries (not included)
Battery Life:	>2000 tests with alkaline batteries
Electromagnetic Compliance (EMC):	Emitted Interference - EN 61326; Immunity to Interference - EN 61326
Waterproof Rating:	Exceeds IP67
Instrument Weight:	140 g (5 oz)
Instrument Dimensions:	5 (W) x 3.5 (D) x 16.5 (H) cm; (2 x 1.4 x 6.375 in)
Government Compliance:	European CE Mark



Industrial Test Systems, Inc.
1875 Langston Street
Rock Hill, SC 29730
800.861.9712
803.329.9712
its@sensafe.com
www.sensafe.com/

EXACT AND EASY AS 1, 2, 3

