

POOL CHECK™

eXact™ Strip

PART NUMBER 481648

The eXact™ Strip CI Total (481648), in conjunction with the eXact™ Strip CI Free, offers the safest and most convenient delivery system for your Total Chlorine testing with the eXact™ Meter. All reagents, as identified in the Standard Methods AWWA Handbook (4500-Cl G.), are contained in the eXact™ strip pads.



Pool Check™ eXact™ Strip For Total Chlorine

(For Use With eXact™
1,2,3,& 9 Meters)

Available For Private Label.

Test Procedure (eXact™ 1 meter example):

- Step 1:** Remove one eXact™ Strip CI Free from the bottle. Recap the bottle immediately. Set strip in a dry place.
- Step 2:** Rinse supplied plastic vial 1 or 2 times and fill to line with pool water sample. DO NOT OVERFILL! Dry outside of vial with a soft paper or cloth towel.
- Step 3:** Lift the chamber lid and insert plastic vial. Close lid.
- Step 4:** Press the "Menu" key to switch the meter on and display the "Cl" symbol.
- Step 5:** Press the "B" key to blank the meter to 0.
- Step 6:** Open the chamber lid and dip the eXact™ Strip CI Free into the plastic vial for 20 seconds with gentle back and forth motion as illustrated.
- Step 7:** Remove and discard the strip; immediately close the lid and push the "R" key. Record result.
- Step 8:** Remove one eXact™ Strip CI-Total from the bottle. Recap the bottle immediately.
- Step 9:** Open the chamber lid and dip the eXact™ Strip CI-Total into the plastic vial for 20 seconds with gentle back and forth motion.
- Step 10:** Remove and discard the strip; immediately close the lid and push the "R" key. Read the display for Total Chlorine in ppm (parts per million). Wait 30 seconds and read again. If the result is essentially unchanged, use this as your Total Chlorine value. Record your results.

Detection Range:

Total Chlorine: 0-5.00 mg/L

Packaging:

Bottle of 50 eXact™ strips

DIGITAL POOL & SPA TESTING

INDUSTRIAL TEST SYSTEMS, Inc.

1875 Langston Street, Rock Hill, SC 29730

Phone: 1-800-861-9712 Fax: 1-803-329-9743

For International: 001-803-329-9712 ext 220 (Pablo)

Web: www.poolcheckonline.com Email: its@cetlink.net



Member of

